



Digi-Sense® TraceableGO™ Bluetooth Datalogging Thermometer

Bluetooth Datalogger Thermometer fills
in the unknowns between trips

- Press START to begin TRIP monitoring
- Place device inside a small cooler or even an entire pallet of material
- Once a TRIP has ended, double-press START/STOP to enable Bluetooth and export data using the FREE TraceableGO™ app
- TraceableGO mobile app immediately identifies if the contents experienced conditions outside user-defined parameters
- Optional: Ability to store TRIP data with a TraceableLIVE™ Account for only \$30/month for an unlimited number of devices

Easy to use

Ideal transit partner for monitoring materials between trips. Safely clinical samples, pharmaceuticals and food items to any location. With the TraceableGO mobile app, view if an alarm was triggered, and generate an instant data report. Device stores up to 90 alarm events, records readings once every 5 minutes by default, or the user may adjust the reading interval between one minute to once every 12 hours.



Download FREE
TraceableGO Mobile APP



Bluetooth Technology

TraceableGO™ Bluetooth devices are pre-programmed with alarm values. Broad compatibility easy Bluetooth connection works with any Bluetooth-enabled devices. Once TraceableGO™ arrives, enable the Bluetooth transfer to a smartphone, open the TraceableGO™ app (available on iTunes or Google Play) pair the device to smartphone download the recorded data since the device was enabled and send a report directly from a mobile device.



Range	Resolution	Accuracy	Size	Cat. No.
-20 to 70°C (-4 to 158°F)	0.1°	±0.4C between -10 and 70°C, otherwise ±0.5°C	3.5 x 2 x 0.79"	MW-18004-12



ColeParmer.com



Digi-Sense® TraceableGO™ Bluetooth Datalogging Hygrometer

Bluetooth Datalogger Hygrometer fills in the unknowns between trips

- Press START to begin TRIP monitoring
- Place device inside a small cooler or even an entire pallet of material
- Once a TRIP has ended, double-press START/STOP to enable Bluetooth and export data using the FREE TraceableGO™ app
- TraceableGO mobile app immediately identifies if the contents experienced conditions outside user-defined parameters
- Optional: Ability to store TRIP data with a TraceableLIVE™ Account for only \$30/month for an unlimited number of devices

Easy to use

Ideal transit partner for monitoring materials between trips. Safely clinical samples, pharmaceuticals and food items to any location. With the TraceableGO mobile app, view if an alarm was triggered, and generate an instant data report. Device stores up to 90 alarm events, records readings once every 5 minutes by default, or the user may adjust the reading interval between one minute to once every 12 hours.



Download FREE
TraceableGO Mobile APP



Bluetooth Technology

TraceableGO™ Bluetooth devices are pre-programmed with alarm values. Broad compatibility easy Bluetooth connection works with any Bluetooth-enabled devices. Once TraceableGO™ arrives, enable the Bluetooth transfer to a smartphone, open the TraceableGO™ app (available on iTunes or Google Play) pair the device to smartphone download the recorded data since the device was enabled and send a report directly from a mobile device.



Range	Resolution	Accuracy	Size	Cat. No.
0 to 95% RH, (non-condensing)	0.1%	±3% RH between 5 to 75%, otherwise ±5% RH	3.5 x 2 x 0.79"	MW-18004-13
-20 to 70°C (-4 to 158°F)	0.1°	±0.4°C between -10 and 70°C, otherwise ±0.5°C		

Contact Us

UK

T: +44 (0) 1480 272279
E: info@coleparmer.co.uk

9 Orion Court, Ambuscade Road,
Colmworth Business Park, St Neots,
Cambridgeshire, PE19 8YX

Germany

T: +49 (0) 9377 92030
E: sales@coleparmer.de

France

T: +33 (0) 1486 37800
E: cpcontact@coleparmer.com

Italy

T: +39 (0) 1313 89513
E: itsales@coleparmer.com

USA

T: +1 847 549 7600
E: sales@coleparmer.com

ColeParmer.com